

COLD WATER TROUBLESHOOTING INDEX

1. Cold Water is not Cold (41° +/- 5° F)

1. Cold Water is not Cold (41° +/- 5° F)

Possible Reason	Solution
No power or refrigeration elements	Check that the Red Heater and Compressor switch is on. Turn Red Heater and Compressor Switch on. I = ON
Tank has run out of cold water.	Wait for cold tank to chill water to temperature prior to
Cold tank capacity is 4 liters for Tower and 2 liters for Counter Top.	dispensing more cold water.
	A greater capacity of <i>Waterlogic</i> Water Systems is available.
Cold Water Thermostat	Check continuity of thermostat with multimeter. Replace thermostat as required.
Refrigerant has run out	Run compressor for at least ten minutes. If condenser is not warm, then refill the refrigerant.
Compressor problem	If Compressor is not running, repair or replacement is needed.

Ecostream Elite Manual Page 64 - Revision: 10-31-21